
KITCHEN DRAWER DISH BASKET INSTALLATION INSTRUCTION (HINGE STYLE)

01 Name of each part




02 Product

Item No.	PO6284 (600)		PO6284 (700)	PO6284 (800)	PO6284 (900)	
Product size	564 × 523 × 244		664 × 523 × 244	764 × 523 × 244	864 × 523 × 244	
Carton size	690 × 556 × 300		790 × 556 × 300	890 × 556 × 300	990 × 556 × 300	
Net weight	≈10.9		≈11.7	≈12.7	≈13.3	
Gross weight	≈12.6		≈13.4	≈14.6	≈15.3	
Metrial surface treatment		Metal parts: Aluminum/fluorocarbon spraying			Plastic parts: ABS	
Implementation Standards GB/T 10125						

03 Cabinet Installation Requirements

1.Cabinet installation dimensions shall follow the diagram below (Default panel thickness: 18mm. For 16mm panels, install 2mm shims on both sides of the slide rails).





TALLSEN

04 Product installation instruction

1 Installation of drawer slides:


- 1.Use the drawer slides installation template to drill holes according to the requirements shown in the diagram;
- 2. Flush against the cabinet side panel, then install the drawer slides.





2 Installation of the basket:

- 1. According to the diagram, connect the slide rail hook to the rear end of the basket;
- 2. Push the upper slide drawer to the end, until the upper rail hooks engage the basket rear. From top to bottom, press the slide drawer to lock the rail.




TALLSEN



3 Door panel installation:

- 1. Use the door panel installation template to drill holes according to the requirements shown in the figure; (Default: Slide rail bottom and door panel bottom installed flush)
- 2. Use screws to fix the door panel.







Note:

- 1. By default, the bottom of the door panel is installed flush with the bottom of the slide rail, i.e., h = 0.
- 2. If the door panel extends below the bottom of the slide rail, height h is added.



- 1.Adjust the guide screw A to adjust the door panel forward and backward (clockwise, the door panel moves backward, counterclockwise, it moves forward);
- 2.Adjust the guide screw B to adjust the door panel up and down (clockwise, the door panel moves downward, counterclockwise, it moves upward);
- 3. After the door panel is adjusted, tighten the screws.















В Downward







05

TALLSEN

5 Storage box installation:

- 1. Hang the storage box along the door panel and onto the hook;
- 2. Install the door panel decorative cover.





6 Product testing:

1. Test the smoothness of the guide rail and whether the door panel flips normally;

2. Installation is complete.

